



# Kitronik uncased USB stick

Part code: 4115



## Shorter version

Carefully snap the board along the line of the rectangle nearest the IC.

